




Ersatzteilliste

#	Beschreibung	Art.-Nr.	PG
1	Griff	80.312815.1.09	11
2	Griffhülse	80.034400.1.09	9
3	Wandrosette	80.034410.1.09	8