





### Ersatzteilliste

#	Beschreibung	Art.-Nr.	PG
1	Griffhebel	80.425900.1.05	<b>13</b>
2	Glockenkappe	80.075200.1.05	<b>5</b>
3	Konterring für Kartusche	80.500000.1.09	<b>2</b>
4	Keramik-Kartusche	80.195300.1.09	<b>7</b>
5	Rückflussverhinderer	80.120900.1.05	<b>8</b>
6	S-Anschluss mit Rosette	80.110900.1.05	<b>7</b>
7	Umsteller	80.065400.1.05	<b>10</b>
8	Perlator M28x1	80.056400.1.05	<b>9</b>