





Ersatzteilliste

#	Beschreibung	Art.-Nr.	PG
1	Griffhebel	80.425900.1.05	13
2	Glockenkappe	80.075200.1.05	5
3	Konterring für Kartusche	80.500000.1.09	2
4	Keramik-Kartusche	80.195300.1.09	7
5	Perlator M24x1	80.056300.1.05	8
6	Zierring	80.263000.1.05	8
7	Befestigung Satz	80.209100.1.09	3
8	Flexschlauch M10x1x350x3/8	80.037700.1.09	4