





## Ersatzteilliste

#	Beschreibung	Art.-Nr.	PG
1	Griff	80.361693.1.01	8
2	Griffhülse	80.366006.1.01	5
3	Wandrosette	80.362763.2.01	6
	Griffhülse	80.366006.1.01	5