





Ersatzteilliste

#	Beschreibung	Art.-Nr.	PG
1	Griff	80.361693.1.14	9
2	Griffhülse	80.366006.1.14	5
3	Wandrosette	80.362763.2.14	7